

Illustrations by Joel Bra

46 H&H JUNE 2014 SEE SOURCE GUIDE



48 H&H JUNE 2014 SEE SOURCE GUIDE

DESIGN LESSON



2. Retro

Inspired by campaign chests, with their metal trim and historical charm, this vintage-look bar is painted a vibrant green and accented with gold, which picks up on other

hits of warm metals throughout the room. Set on a raised platform to give it extra height, it's the perfect spot to serve drinks during parties. Plus, the spacious interior has the right proportions for bottle storage.

SHOPPING LIST



x 29%" w. x 12%" d. \$84. At Ikea.

4" utility handles.
\$3 each. At Lee
Valley. 1" x 5" x 8'
poplar, \$19, corner
brackets, \$4/4. At
The Home Depot.

Shamrock

(SW 6454),

Sherwin-Williams.



DIRECTIONS

STEP ONE: BUILD A STURDY PLATFORM

This is really just a frame made out of one length of $1" \times 5" \times 8"$ poplar. To achieve the recessed base, make your box 2" smaller than the cabinet on all sides. The base of our cabinet was $30" \times 12"$, so we made the platform $26" \times 8"$.

STEP TWO: PREPARE AND PAINT

Assemble the cabinet according to Ikea's instructions, then paint the surfaces following the directions in Step Two on page 48.

STEP THREE: ATTACH THE HARDWARE

Attach the handles to the door, making sure they're

centred vertically. Screw the corner brackets onto the doors and on either side of the cabinet, aligning them as close to the edges of the wood as possible. STEP FOUR: PUT IT ALL TOGETHER

Before attaching the doors, centre the cabinet on the platform, then predrill through the base of the cabinet into the platform and attach with standard wood screws. Once the platform is secured, attach the doors. ABOVE: Bench, chair, rug, Elte; lamp, West Elm; dish, tray, Absolutely North; pitcher, glasses, Cynthia Findlay Antiques; flooring, Karndean; wall colour, Potpourri Green (50GY 66/111), CIL.

50 H&H JUNE 2014 SEE SOURCE GUIDE



DIRECTIONS

STEP ONE: TRIM THE CABINET DOWN TO SIZE

The cabinet will be too deep for a powder room application, so you'll need to cut the top, bottom and side pieces and interior shelves down by 6" before assembling. Once you've cut off the excess wood with a circular saw, sand the rough edges smooth.

STEP TWO: PREPARE AND PAINT

Assemble the cabinet, leaving the door off for now, then paint the surfaces following the directions in Step Two on page 48.

STEP THREE: ATTACH THE MIRROR,

THEN THE DOOR

Centre the mirror on the cabinet door, then affix — we used Liquid Nails Mirror Adhesives. Attach the door to the body of the cabinet.

STEP FOUR: HANG THE CABINET

Hang the cabinet following the directions in Step Four on page 48.

BELOW: Hang the cabinet 14" from the top of the vanity so it doesn't crowd the sink. An oval mirror is another clever idea; it gives a traditional, cameo-like effect and doesn't cover up as much of the colour as a rectangular mirror would. Wallpaper by Thibaut, Kravet; vanity, faucet, Taps; towel, West Elm.



52 H&H |UNE 2014 SEE SOURCE GUIDE